

Installation manual
(Original instructions)

EN

Panasonic[®]

N421157A - Rev.00 - 11/2024

Aquarea Air Duct Multi Zone

P-FSQ** series

First of all, we would like to thank you for having chosen one of our units.

As you will realise, you have made a winning choice by purchasing a product that represents the state of the art in domestic air-conditioning technology.

Thanks to the product you have purchased and by following the suggestions in this manual, you will benefit from optimal environmental conditions with the lowest possible energy investment.

Panasonic Corporation

Compliance

This unit complies with European directives:

- Low voltage 2014/35 / EU
- Electromagnetic compatibility 2014/30 / EU

Markings



CONTENTS

Compliance	2
----------------------	---

1. General information 4

1.1 About the manual	4
1.2 General Warnings	5
1.3 Basic safety rules.	5
1.4 Disposal	6

2. Product introduction 7

2.1 Identification	7
2.2 Destination of use	7
2.3 Description of the appliance	7
2.4 List of external components	8
2.5 List of internal components	8
2.6 Configurations	9
2.7 Compatible accessories	10

3. Installation 12

3.1 Preliminary Warnings	12
3.2 Reception	12
3.3 Dimensions and weights with packaging	12
3.4 Handling with packaging	12
3.5 Storage.	13
3.6 Unpacking.	13
3.7 Handling without packaging.	14
3.8 Installation site.	14
3.9 Minimum installation distances.	15
3.10 Positioning	16
3.11 Hydraulic connections.	17
3.12 Condensate drain connection	19
3.13 System charging	20
3.14 Correspondence between the air supply channel and the electrical panel.	21
3.15 Aeraulic connections.	22
3.16 Electrical connections	23

4. Wall mounted control PCZ-EEB749 . . . 26

4.1 Interface	26
4.2 Installation	26
4.3 Single connection diagram	28
4.4 Multiple connection diagram	29
4.5 Connection diagram for S version.	30
4.6 Connections.	31
4.7 Functions	32

5. Wall mounted control PCZ-EFB749 . . . 36

5.1 Interface	36
5.2 Installation	36
5.3 Single connection diagram	38
5.4 Multiple connection diagram	39
5.5 Connection diagram for S version.	40
5.6 Connections.	41
5.7 Functions	42

6. Start-up 46

6.1 Preliminary Warnings	46
6.2 First start-up	46
6.3 Plant delivery	47
6.4 Switching off for extended periods	47

7. Maintenance 48

7.1 Routine maintenance	48
-----------------------------------	----

8. Faults and remedies 52

8.1 Preliminary Warnings	52
8.2 Troubleshooting Table.	52
8.3 Alarm table and card flashes.	53

9. Technical information 54

9.1 Technical data.	54
9.2 Dimensions	56

1. GENERAL INFORMATION

1.1 About the manual

This manual was written to provide all the explanations for the correct management of the appliance.

- ⚠ This instruction manual is an integral part of the appliance and must therefore be kept in a safe place and must ALWAYS accompany the appliance even if it is passed on to another owner or user, or transferred to another plant. If it is damaged or lost, download a copy from the website.
- ⚠ Read this manual carefully before proceeding with any operation and follow the instructions in the individual chapters.
- ⚠ Specific warnings are given in each chapter of the document and should be read before starting operations.
- ⚠ The manufacturer accepts no liability for damage to persons or property resulting from failure to observe the regulations contained in this booklet.
- ⚠ This document is confidential under the terms of the law and may not be reproduced or passed on to third parties without the express authorisation of the company.

Editorial pictograms

The pictograms in the following chapter provide quick and unambiguous information necessary for the correct and safe use of the machine.

Related to safety

⚠ High risk warning (bold text)

- The operation described above presents a risk of serious physical injury, fatality, major damage to the appliance and/or to the environment if not carried out in compliance with safety regulations.

⚠ Low risk warning (plain text)

- The operation described above presents a risk of minor physical injury or minor damage to the appliance and/or to the environment if not carried out in compliance with safety regulations.

⊘ Prohibition (normal text)

- Marks actions that absolutely must not be done.

❗ Important information (bold text)

- This indicates important information that must be taken into account during the operations.

In the texts

Purpose of the actions

- Actions required

Expected responses following an action

- Lists

In the figures

- 1 The numbers indicate the individual components.

A Capital letters indicate a combination of components and dimensions.

- ① The white numbers in black marks indicate a series of actions to be carried out in sequence.

- Ⓐ The black letter in white identifies an image when there are several images in the same figure.

Pictograms on the product

Symbols are used in some parts of the appliance:

Related to safety



Read the instruction manual

Read the instructions carefully before performing any operation on the appliance.



Instruction manual

Read the information available in the technical documentation of the appliance.



Attention electrical hazard

- Warns relevant personnel of the presence of electricity and the risk of electric shock.

Recipients

User

Non-expert person capable of operating the product in safe conditions for people, for the product itself and the environment, interpreting an elementary diagnostic of faults and abnormal operating conditions, carrying out simple adjustment, checking and maintenance operations.

Installer

Expert person qualified to position and connect (hydraulically, electrically, etc.) the unit to the plant; this person is responsible for handling and correct installation according to the instructions provided in this manual and the national standards currently in force.

Service

Expert and qualified person authorised directly by the manufacturer to carry out all routine and supplementary maintenance operations, as well as every adjustment, check, repair and replacement of parts necessary during the life of the unit itself.

Organisation of the manual

The manual is divided into sections each dedicated to one or more target groups.

General information

It addresses all recipients.

It contains general information and important warnings that should be known before installing and using the appliance.

Product introduction

Addressed to all recipients, contains general information on the product.

Installation and Operation

It is addressed exclusively to the installer.

Contains specific warnings and all information necessary for positioning, mounting, connecting the device and operation.

Commissioning, maintenance and troubleshooting

They are addressed exclusively to the Technical Assistance Centre.

It contains specific warnings useful information for the most common commissioning and routine maintenance.

Technical information

It addresses all recipients.

It contains detailed technical information about the appliance.

1.2 General Warnings

- ⚠ Specific warnings are given in each chapter of the document and should be read before starting operations.
- ⚠ All personnel involved must be aware of the operations and dangers that may arise when beginning all unit installation operations.
- ⚠ Installation performed outside the warnings provided in this manual and use of the appliance outside the prescribed temperature limits will invalidate the warranty.
- ⚠ Any contractual or extra-contractual liability for damage caused to persons, animals or property, due to installation, adjustment and maintenance errors or improper use is excluded. All uses not expressly indicated in this manual are not permitted.
- ⚠ The installation of the appliances must be carried out by a qualified company which, on completion of the work, will issue a declaration of compliance to the person in charge of the plant in accordance with the regulations in force and the instructions provided in the instruction booklet accompanying the appliance.
- ⚠ First start-up and repair or maintenance operations must be carried out by the Technical Assistance Centre or by qualified personnel following the provisions of this manual.
- ⚠ Do not modify or tamper with the appliance as this can lead to dangerous situations.
- ⚠ Use suitable accident-prevention clothing and equipment during installation and/or maintenance operations.

tions. The manufacturer is not liable for the non-observance of the current safety and accident prevention regulations.

- ⚠ In the event of spillage of liquids, oil, set the system's main switch to "off" and close any water taps. Call the authorised Technical Assistance Centre or professionally qualified personnel as soon as possible and do not work on the appliance yourself.
- ⚠ When replacing components, use only original spare parts.
- ⚠ The manufacturer reserves the right to make changes to its models at any time to improve its product, without prejudice to the essential characteristics described in this manual. The manufacturer is not obliged to add such modifications to machines previously manufactured, already delivered or under construction.
- ⚠ The appliance can be used by children aged 8 years and above and by persons with reduced physical, sensory, or mental capabilities, or those lacking experience or necessary knowledge, provided they are under supervision or have been given instructions concerning the safe use of the appliance and understand the hazards involved. Children should not play with the appliance. Cleaning and maintenance intended to be carried out by the user should not be done by children without supervision.

1.3 Basic safety rules

We would like to remind you that the use of products that use electricity and water involves observing certain basic safety precautions such as:

- ⊖ It is forbidden to touch the appliance with wet or damp body parts.
- ⊖ It is forbidden to carry out any operation before disconnecting the appliance from the power supply by setting the plant master switch to "off".
- ⊖ It is forbidden to modify the safety or adjustment devices without the authorisation and instructions of the appliance manufacturer.
- ⊖ It is forbidden to pull, unplug or twist the electrical cables coming out of the appliance, even if it is disconnected from the mains supply.
- ⊖ It is forbidden to introduce objects and substances through the openings provided for the intake and delivery of air.
- ⊖ It is forbidden to open the access doors to the internal parts of the appliance without first setting the plant master switch to "off".
- ⊖ It is forbidden to dispose of packaging material and leave it within reach of children as it can be a potential source of danger.

1.4 Disposal



The symbol on the product or packaging indicates that the product should not be treated as normal household waste. Instead, it should be taken to an appropriate collection point for recycling of electrical, electronic, and battery equipment.

Proper disposal of this product avoids harm to humans and the environment and promotes the reuse of valuable raw materials.


For more detailed information about the recycling of this product, contact your local city office, your household waste disposal service or the shop where you purchased the product.

Illegal disposal of the product by the user involves the application of the administrative sanctions provided for by the regulations in force.

This provision is only valid in the EU Member States.

⚠ Avoid disassembling the appliance yourself.

⚠ **Contact an authorised Technical Assistance Centre to disassemble the appliance.**



This symbol could be used in combination with a chemical symbol.


In such case, it complies with the requirements set by the directive for the chemical substance involved.

2. PRODUCT INTRODUCTION

2.1 Identification

The appliance can be identified by the rating plate:

1. Technical rating plate



Technical rating plate

This shows the technical and performance specifications of the appliance.

⚠ Tampering with, removing or missing identification plates does not allow the product to be reliably identified by its serial number and therefore invalidates the warranty.

2.2 Destination of use

Designed for ceiling installation, this compact unit is optimal for air conditioning systems.

⊖ Any use of the appliance other than that indicated is prohibited.

2.3 Description of the appliance

Structure: high-strength, self-supporting frame in galvanized sheet metal with internal thermal and acoustic insulation.

Fans: low-energy consumption forward-curved EC centrifugal fans for reduced noise.


Filters: flat with Coarse filtration class.

Exchange coil: coil optimized for the best heat exchange

Models: 4 sizes with different flow rates are available.


2.4 List of external components

- | | |
|----|--|
| 1. | Electrical panel |
| 2. | Hydraulic connection water outlet from the unit including air vent |
| 3. | Condensate drain |
| 4. | Hydraulic connection water inlet to the unit including air vent |




2.5 List of internal components

- | | | | |
|----|---------------|----|--------|
| 1. | Fan | 3. | Filter |
| 2. | Hydronic coil | | |

















2.6 Configurations

- | | | |
|----|------------------|--|
| 1. | Configuration O: | hydraulic connections on the left and electrical panels on the right |
| 2. | Configuration Y: | hydraulic connections on the right and electrical panels on the left |



2.7 Compatible accessories

Description		Code
Control panels		
	LED electronic control panel with touch interface, wall mounted complete with thermostat and room temperature and relative humidity probe. Cable connection. White colour	PCZ-EEB749
	LED electronic control panel with touch interface, wall-mounted complete with thermostat and room temperature and relative humidity probe with integrated Wi-Fi module. Cable connection. White colour	PCZ-EFB749
Side Conversion kit		
	Side Conversion kit	PCZ-BB0646
Valves		
	2-way valve with motor	PCZ-V20139
	3-way valve with motor	PCZ-V30361
Return plenum		
	Return plenum with 2 circular inlets 160mm	PCZ-AHRD0466
	Return plenum with 3 circular inlets 160mm	PCZ-AHRD0467
	Return plenum with 4 circular inlets 160mm	PCZ-AHRD0468
	Return plenum with 5 circular inlets 160mm	PCZ-AHRD0469
Plenum kit for rear intake		
	Plenum kit for rear intake	PCZ-AHRD0522
	Plenum kit for rear intake	PCZ-AHRD0523
	Plenum kit for rear intake	PCZ-AHRD0524
	Plenum kit for rear intake	PCZ-AHRD0525

Description		Code
Plenum kit for external air connection with damper for room recirculation		
	Plenum kit for external air connection with damper for room recirculation	PCZ-AHRD0640
	Plenum kit for external air connection with damper for room recirculation	PCZ-AHRD0641
	Plenum kit for external air connection with damper for room recirculation	PCZ-AHRD0642
	Plenum kit for external air connection with damper for room recirculation	PCZ-AHRD0643
Plate for ducting damper for external air		
	Plate for ducting damper for external air	PCZ-AHRD0652
	Plate for ducting damper for external air	PCZ-AHRD0653
	Plate for ducting damper for external air	PCZ-AHRD0654
	Plate for ducting damper for external air	PCZ-AHRD0655
Rear intake plenum kit for external air kit		
	Rear intake plenum kit for external air kit	PCZ-AHRD0657
	Rear intake plenum kit for external air kit	PCZ-AHRD0658
	Rear intake plenum kit for external air kit	PCZ-AHRD0659
	Rear intake plenum kit for external air kit	PCZ-AHRD0660
Telescopic kit for rear intake or directly coupled to external air damper		
	Telescopic kit for rear intake or directly coupled to external air damper	PCZ-AHRD0662
	Telescopic kit for rear intake or directly coupled to external air damper	PCZ-AHRD0663
	Telescopic kit for rear intake or directly coupled to external air damper	PCZ-AHRD0664
	Telescopic kit for rear intake or directly coupled to external air damper	PCZ-AHRD0665
Grille for telescopic kit for external air damper		
	Grille for telescopic kit for external air damper	PCZ-AHRD0667
	Grille for telescopic kit for external air damper	PCZ-AHRD0668
	Grille for telescopic kit for external air damper	PCZ-AHRD0669
	Grille for telescopic kit for external air damper	PCZ-AHRD0670
Non-return damper		
	Non-return damper	PCZ-AHRD0519

3. INSTALLATION

3.1 Preliminary Warnings

- ⚠ **For detailed information on the products, refer to chapter "Technical information" p. 54.**
- ⚠ The installation must be carried out by the installer. There is a risk of water leakage, electric shock or fire if the installation is not performed correctly.
- ⚠ During installation, it is necessary to observe the precautions mentioned in this manual, and on the labels affixed to the inside of the appliances, as well as to take

every precaution suggested by common sense and the safety regulations in force at the place of installation.

- ⚠ Using only the supplied installation-specific components is recommended. Use of different components could lead to water leakage, electric shock or fire.
- ⚠ Failure to apply the indicated rules may cause malfunctions of the appliances and relieves the manufacturer from any warranty and from any damage caused to persons, animals or property.

3.2 Reception

Preliminary Warnings

- ⚠ Upon receipt of the package check that it is not damaged, otherwise accept the goods with reserve, producing photographic evidence of any damage.
- ⚠ In the event of damage, notify the shipper by registered mail with return receipt within 3 days of receipt. Presenting photographic documentation, similar information should also be sent by email to the manufacturer.
- ⚠ No reports of damage will be taken into account later than 3 days after delivery.


Package description

The packaging is made of suitable material and carried out by experienced personnel.

The units are all checked and tested and are delivered complete and in perfect condition.

The appliance is shipped in standard packaging consisting of a cardboard box and a set of polystyrene foam protectors, placed on a wooden pallet and secured with straps.

3.3 Dimensions and weights with packaging



Models	u.m.	30	45	60	75
Packaging dimensions (1)					
Width	mm	925	1125	1325	1650
Length	mm	880	880	880	785
Height	mm	275	275	275	275
Weight	kg	31,0	42,0	51,0	61,0
1. Excluding pallet					

3.4 Handling with packaging

Preliminary Warnings

- ⚠ The unit may only be handled by qualified personnel adequately equipped and with equipment suitable for the weight and dimensions of the unit.

- ⚠ Before each handling operation, check the lifting capacity of the machinery used in accordance with the indications on the packaging.
- ⚠ When the load is lifted from the ground, stay clear of the immediate and surrounding area.


- ⚠ Check the information on the packaging for the amount of stackable packages.

- ⚠ In manual operations, the maximum weight per person required by current legislation must always be observed.

Handling

With pallet:

- use a forklift



Without pallet:

- use a forklift
- ⚠ The unit can only be moved manually for short trips in exceptional cases. In this case it is necessary to carefully check that the weight of the unit does not exceed what is stipulated by the regulations with respect to the number of people employed.

3.5 Storage

Preliminary Warnings


- ⚠ Stored in accordance with the applicable national regulations.
- ⚠ Store in a closed environment protected from the weather, off the ground by means of sleepers or pallets with temperatures not below 0 °C, up to a maximum of 40 °C.

3.6 Unpacking

Preliminary Warnings

- ⚠ Check that the individual components are present.
- ⚠ Check that no components were damaged during transport.
- ⚠ Dispose of the packaging components following the applicable waste disposal regulations. Check for disposal arrangements with your municipality.
- ⚠ Handle with care.
- ⚠ The packing material (cardboard, staples, plastic bags, etc.) must not be dispersed or abandoned in the surrounding environment and must be kept out of children reach, as it can be dangerous.

Removing the packaging



To remove the packaging:

- ▶ use a cutter
- ▶ open the cardboard packaging
- ① To aid removal of the product, also cut the vertical edges.
- ▶ remove the accompanying components
- ▶ remove the polystyrene elements

- ▶ remove the appliance from the box

Accompanying material

They are included with the appliance, inside the packaging:

- Installer manual
- Labels/stickers provided on the unit
- ⚠ Check the presence of the individual components.

3.7 Handling without packaging

Preliminary Warnings

- ⚠ The appliance must be handled only by qualified personnel, adequately equipped and with equipment suitable for the weight and dimensions of the appliance.
- ⚠ The unit must be handled using non-slip gloves.
- ⚠ The unit may only be handled by qualified personnel adequately equipped and with equipment suitable for the weight and dimensions of the unit.
- ⚠ Before each handling operation, check the lifting capacity of the machinery used in accordance with the indications on the packaging.
- ⚠ When the load is lifted from the ground, stay clear of the immediate and surrounding area.

- ⚠ Check the information on the packaging for the amount of stackable packages.
- ⚠ In manual operations, the maximum weight per person required by current legislation must always be observed.

Movement methods

- ▶ use a fork lift, scaffolding or other suitable lifting system
- ⚠ The unit can only be moved manually for short trips in exceptional cases. In this case it is necessary to carefully check that the weight of the unit does not exceed what is stipulated by the regulations with respect to the number of people employed.

3.8 Installation site

The location of the appliance must be determined by the plant engineer or a competent person and must take into account both purely technical requirements and any national/local legislation in force.

The appliance is intended to be installed indoors in a horizontal position fixed to the ceiling.

- ⚠ The appliance is declared IPX0 protected, therefore not suitable for installation outdoors or in rooms with the presence of water (swimming pool, etc.).

Preliminary Warnings

- ⚠ Avoid installing the unit in the vicinity of:
 - obstacles or barriers that cause recirculation of the exhaust air
 - narrow places where the sound level of the appliance can be enhanced by reverberations or resonances
 - environments with the presence of flammable or explosive gases
 - very damp environments (laundries, greenhouses, bathrooms with high humidity, etc.) to prevent the formation of condensation on the external panels of the unit
 - environments with the presence of flammable or explosive gases or flammable fluids
 - solar radiation and proximity to heat sources
- ⚠ **Avoid installing the unit in the vicinity of the sea. Salty atmospheres cause corrosion and oxidation of the internal components, compromising the functioning of the unit.**


- ⚠ Avoid placing the unit within 1 metre of radio and video equipment.
- ⚠ Do not install above heat sources.
- ⚠ Ensure that:
 - the installation site of the unit must be chosen with the utmost care to guarantee adequate protection from shocks and consequent damage
 - the supporting surface is capable of supporting the weight of the appliance
 - the supporting surface does not affect load-bearing building elements, piping or power lines
 - the functionality of load-bearing elements is not compromised
 - there are no obstacles to the free circulation of air through the holes (plants, leaves...)
 - the appliance must be installed in a position where it can be easily serviced
 - the safety distances between the units and other appliances or structures are scrupulously respected so that the air entering and leaving the fans is free to circulate
- ⚠ If the unit is installed incompletely or on an unsuitable surface, it could cause damage to persons or property if it becomes detached.
- ⚠ The appliance must not be in a position where the air flow is aimed directly at a person.
- ⚠ Provide the following:
 - a drain nearby for the outflow of condensation
 - a compliant power supply nearby

- fastening elements suitable for the type of support

3.9 Minimum installation distances

The clearance zones for the installation and maintenance of the appliance are shown in the figure. Established spaces are necessary to avoid barriers to airflow and allow for normal cleaning and maintenance.


⚠ Make sure that there is sufficient space to allow the panels to be removed for routine and supplementary maintenance operations.



Models	u.m.	30	45	60	75
Minimum distances					
A	mm	350	350	350	350
B	mm	350	350	350	350
C	mm	50	50	50	50
D	mm	250	250	250	250

Hatch dimensions

⚠ For horizontal installation in a false ceiling, it is mandatory to create an access hatch for the inspection and maintenance of the device.




Models	u.m.	30	45	60	75
Hatch dimensions					
A	mm	795	795	795	795
B	mm	1490	1690	1890	2140
C	mm	350	350	350	350
D	mm	350	350	350	350
E	mm	50	50	50	50

3.10 Positioning


Preliminary Warnings

- ⚠ Check that:
- the surface supports the weight of the appliance
 - the surface does not affect piping or power lines
 - the functionality of load-bearing elements is not compromised

Positioning the unit



⚠ Use the 4 mounting holes on the upper side of the unit.



- ⚠ Check the correct orientation of the unit.
- ▶ mark the position of the fixing holes
- ▶ use fixing systems appropriate for the type of supporting surface and the weight of the unit
- ▶ secure the unit to the fixing system

Check that:

- it is levelled
- the minimum installation distances are respected

3.11 Hydraulic connections

Chemical and physical characteristics of water


The quality of the water used must comply with the characteristics listed in the following table; otherwise, a treatment system should be provided.

Water content	Unit of measure	Concentration
Chlorides (Chloride)	ppm	< 50
Dissolved oxygen	ppm	< 0,1
Ammonia (NH ₃)	ppm	< 0,5
Sulfate (SO ₄)	ppm	< 70
Bicarbonate (HCO ₃)	ppm	70 ÷ 300
Bicarbonate/Sulfate ratio (HCO ₃ /SO ₄)	-	> 1,0
pH	-	7,5 ÷ 9,0
Total hardness	dH	4,5 ÷ 8,5
Phosphate (PO ₄)	ppm	< 2,0
Free chlorine (Cl ₂)	ppm	< 0,5
Iron (Fe ³⁺)	ppm	< 0,2
Manganese (Mn ²⁺)	ppm	< 0,05
Free carbon dioxide (CO ₂)	ppm	< 5
Electrical conductivity	µS/cm	10 ÷ 500
Nitrate (NO ₃)	ppm	< 100
Aluminum (Al)	ppm	< 0,2
Ratio of [Ca ²⁺ , Mg ²⁺] to [HCO ₃ ⁻]	-	-
Chlorides (Cl)	ppm	< 50
Hydrogen sulfide (H ₂ S)	ppm	< 0,05

⚠ Incompatible chemical and physical characteristics could compromise the integrity of the hydraulic components of the unit.

- ⚠ Well or groundwater not sourced from the public water supply must always be carefully analyzed and, if necessary, treated with appropriate conditioning systems.
- ⚠ If the hardness of the starting water exceeds the value indicated in the table, a water softening system must be used.
- ⚠ Excessive softening of the water (total hardness < 1.5 mmol/L) could generate corrosive phenomena in contact with metallic elements (pipes or parts of the boiler). Additionally, keep the conductivity value within 600 µS/cm.
- ⚠ Check the chloride concentration in the output after the regeneration of the resins.
- ⊖ It is prohibited to introduce acids into the washing circuit.
- ⊖ It is prohibited to constantly or frequently top up the system, as this can damage the heat exchanger of the device.

Position and dimensions



System connection

To make the connections:

- ▶ position the hydraulic lines
- ▶ support the body of the connection with an additional wrench or spanner to avoid damage
- ▶ tighten the connections
- ▶ check for any leaks
- ▶ insulate the connections with insulation material

- ⚠ The hydraulic lines and joints must be thermally insulated.
- ⚠ Avoid partial insulation of the pipes.
- ⚠ Do not overtighten the connections to avoid damaging the insulation.
- ⚠ Carefully check the insulation seals to prevent condensation formation and dripping.

Connection with 2-way valve



In case of choosing the 2-way valve option:

- electrical connections are required

- connect to the lower outlet

- | | |
|----------|---------------------------------|
| A | Electrical cable entry |
| B | Connection for water inlet pipe |
| C | Thermoelectric motor |

- | | |
|----------|----------------------------------|
| D | Connection for water outlet pipe |
| E | Machine body |



Connection with 3-way valve


In case of choosing the 3-way valve option:

- electrical connections are required

- connect to the lower outlet

A Electrical cable entry
B Connection for water inlet pipe
C Thermoelectric motor

D Connection for water outlet pipe
E Machine body



3.12 Condensate drain connection


Preliminary Warnings

- ⚠ This appliance is equipped with trays for collecting the condensate that is produced during operation. Condensate must be routed to a suitable place for drainage.
- ⚠ If the drainage line runs into a container (tank or other) it must be ensured that the container itself is hermetically sealed and most importantly it must be ensured that the drainage pipe is not immersed in water.
- ⚠ The hole for the condensate pipe must always have an outwards slope.
- ⚠ When connecting the condensate drain, take care not to crush the rubber pipe.

Attachment position


The unit is equipped with a condensate drain connection. The size and position of the condensate drain attachments are shown below.

1. Condensate drain




Connections


1. Condensate drain connection
2. Condensate drain pipe
3. Hose fitting
4. Hose clamp



1. Unit



HT	100 mm
H1	50 mm
H2	50 mm



To connect the condensate drain:

- ▶ connect the drainage pipe to the connection provided on the unit
- ▶ install a siphon on the condensate drainage pipe near the unit
- ▶ direct the condensate drain pipe to a suitable place for draining
- ▶ maintain a minimum slope of 3% towards the drain location
- ▶ insulate junction points

⚠ It is mandatory to install an adequate siphon on the condensate drainage pipe to prevent the negative pressure generated by the fans from obstructing the proper flow of condensate, which could lead to spillage inside the premises.

- ⚠ The drainage system must include a suitable siphon to prevent unwanted air from entering the vacuum system. The siphon also prevents the entry of odours or insects.
- ⚠ The siphon must be fitted with a plug at the bottom or must in any case permit quick dismantling for cleaning.
- ⚠ Use plastic drainage pipes.
- ⚠ Avoid metal pipes.
- ⚠ Make sure all joints are sealed to prevent leakage of water.
- ⚠ Condensate drain pipes must be insulated for both indoor and outdoor sections to avoid condensation on the surface and/or frosting problems. The insulation must be inserted all the way to the condensate drain pipe connection on the unit.
- ⚠ Use pipes with a diameter of 40 mm.

3.13 System charging


To charge the system:

- ▶ open the relief valves on the devices
- ▶ open all the shut-off devices of the system
- ▶ slowly open the filling valve

When water starts coming out of the relief valves:


- ▶ close the relief valves
- ▶ proceed with the filling
- ▶ check that you have reached the nominal pressure specified for the system
- ▶ close the filling valve
- ▶ check the hydraulic tightness of the joints

- ⚠ It is advisable to repeat the operation after the appliance has been running for a few hours.
- ⚠ Periodically check the system pressure.

1. Air relief

3.14 Correspondence between the air supply channel and the electrical panel

- | | | |
|-----------|------------------|--|
| 1. | Configuration O: | hydraulic connections on the left and electrical panels on the right |
| 2. | Configuration Y: | hydraulic connections on the right and electrical panels on the left |



- ⚠ The electrical panel 1 and the supply channel 1 are always positioned near the same corner, regardless of the chosen configuration.
- ⚠ In the electrical panel corresponding to number 1, there is the connection to the power supply, the actuator, and the 2-way and 3-way valves. The electrical panels are in parallel, therefore the connection to the power supply should only be made to number 1.

3.15 Aeraulic connections

Preliminary Warnings


⚠ The sizing of ducting and supply and extract grids must be carried out by a professionally qualified person.

⚠ To prevent the transmission of any vibrations of the machine into the room, an anti-vibration joint should be placed between the fan outlets and the ducts.


⚠ The connecting pipes must be of a suitable diameter and supported so that their weight does not put a strain on the appliance.

Connections


A Extracted air




B Air supply



Extracted air dimensions



Air supply dimensions



Models	u.m.	30	45	60	75
Extracted air dimensions					
A	mm	630	830	1030	1317
B	mm	143	143	143	143
Air supply dimensions					
Connections number		2	3	4	5
Supply air connection	mm	160	160	160	160

3.16 Electrical connections

The appliance leaves the factory fully wired and only requires connection to the power supply, control and any accessories.

Preliminary Warnings

- ⚠ All operations of an electrical nature must be carried out by qualified personnel having the necessary legal requirements, trained and informed about the risks related to such operations.
- ⚠ All connections must be made in accordance with the relevant regulations in force in the country of installation.
- ⚠ Before carrying out any work, make sure that the power supply is switched off.
- ⚠ The unit should only be powered after the plumbing and electrical work has been completed.
- ⚠ References:
 - for electrical connections please refer to the wiring diagrams in this manual, especially for the part concerning the power terminal board
- ⚠ Check that:
 - the mains characteristics are adequate for the power consumption of the appliance, also taking into account any other machinery in parallel operation
 - the power supply voltage and frequency correspond to those specified on the nameplate on the appliance
 - the cables are suitable for the type of laying in accordance with the IEC standards in force
 - the power supply is adequately protected against overloads and/or short circuits
 - the disconnection device is positioned in an easily accessible place to be able to intervene in the event of an emergency
- ⚠ It is mandatory:
 - to connect the appliance to an effective grounding system
 - for units with three-phase power supply, check the correct phase connection
 - provide an all-pole switch with a contact opening distance of at least 3 mm that allows complete disconnection under overvoltage category III conditions
 - Install a ground fault circuit interrupter (GFCI). Failure to install this device could result in electric shock

- ⚠ Use a dedicated power supply circuit. Never use a power supply to which another appliance is also connected due to risk of overheating, electric shock or fire.
- ⚠ For the electrical connection, use a cable of sufficient length to cover the entire distance without any connection. Do not use extension cables. Do not apply other loads on the power supply.
- ⚠ After connecting the interconnection and power supply cables, ensure that the cables are arranged so that they do not exert excessive forces on the covers or electrical panels. Install the covers on the cables. Incomplete connections of the covers can lead to overheating of the terminals, electric shock or fire.
- ⚠ Any replacement of the power cable must only be carried out by qualified personnel and in accordance with current national regulations.
- ⚠ The manufacturer is not liable for any damage caused by the lack of earthing or failure to comply with the specifications in the respective diagrams.
- ⚠ The appliance is equipped with a noise filter as required by current regulations. Use selective residual current circuit breakers to compensate for the micro leakage to earth of this device.
- ⊖ Using gas and water pipes to ground the appliance is prohibited.

Power line dimensioning

Use the tables below for the sizing of the power supply line and its protection device.

These are not average draw or transient peaks, but values to be considered for the correct sizing of the plant and the request of the contractual power (excluding loads due to the normal operation of the building).


- ⚠ Maximum power is reached only in exceptional cases. Therefore, the indicated trip current is suggested to guarantee a balance between machine absorption and incidence in the general system.
- ⚠ The indicated minimum cable cross-section area must be verified according to the actual conditions of the installation: length of the cable, characteristics of the electrical supply, etc.
- ⚠ For units equipped with electrical heating elements, the draw values of the units must be added to those of the heating elements shown in the following tables.

Access to the electrical panel

- ⚠ Access to the electrical panel is only permitted to qualified personnel.

⚠ Before carrying out any work, ensure that the power supply is switched off.

1. Electrical panel closing panel



To access the connections:

- ▶ remove the fixing screws
- ▶ remove the electrical panel closing panel

Connections


Before connecting the unit to the mains power supply, make sure that the disconnecter is open. The power supply of the single-phase unit must be connected to the appropriate terminals, subjected to the action of the isolating switch.

⚠ Use properly sized cables to avoid voltage drops or overheating.

Connection diagram


1. 230/1/50 power supply
2. Disconnecter
3. Power cable

4. FNC MULTI
5. Remote control
6. Control panel communication cable




On-board electrical panel

Connection terminal board



4. WALL MOUNTED CONTROL PCZ-EEB749

4.1 Interface



4.2 Installation

Description


The wall remote control is an electronic LED thermostat with a touch interface, capable of controlling multiple devices equipped with the same electronic board. It is equipped with a temperature and humidity sensor.

⚠ The command can control up to 16 devices.

Mounting

⚠ The control panel for wall control must be installed inside a 503 electrical box.

⚠ Before proceeding with the installation of the wall control panel, it is necessary to prepare the wall for housing the 503 electrical box.




The wall control must be installed:

- on the outside walls
- at a height of approx. 1.5 m above the floor
- away from doors and windows
- away from heat sources such as radiators, fan coils, cookers, direct sunlight

⚠ The wall control is supplied already assembled in the package.


1. Control base
2. Wall control command



Before mounting on the wall:

- Separate the control base from the control panel

1. Fixing screws
2. Control base
3. Holes for fixing to the electrical box
4. 503 electrical box




For wall mounting of the control panel:

- Fix the control base to the 503 electrical box with screws
- Make the connections

⚠ Before making the connections, check that the terminal block of the command is on the right side.

1. 503 electrical box
2. Control base
3. Wall control command



- close the control panel


⚠ Be careful not to crush the wires when closing the control.

4.3 Single connection diagram

M1	M1: DC Inverter fan motor
PE	Ground connection
L-N	Electrical power connection 230 V / 50 Hz / 1 A
Y1	Water solenoid valve (output voltage 230V / 50 Hz / 1 A)
CH/C1	Generator cooling request contact (e.g., chiller or reversible heat pump). It activates in parallel with the solenoid valve output (Y1) with a 1-minute delay when the fan coil is in cooling mode and is on call (clean contact max 1 A)
BO/C2	Generator heating request contact (e.g., boiler or heat pump). It activates in parallel with the solenoid valve output (Y1) with a

1-minute delay when the fan coil is in heating mode and is on call (clean contact max 1 A)


CP	Presence contact (Normally open)
-BA+	Serial connection for remote wall control (respect polarization AB)
IN1	Input for clean contact 1 (not active)
H2/T2	Water temperature sensor 2 pipes
LU	Board for pairing command and device
PU	On-board machine board
RC	Command for wall mounted control



4.4 Multiple connection diagram


1. Command for wall mounted control
2. Device connection terminal block

3. Electronic board
4. Board for pairing command and device



⚠ With multiple command connections, pairing between the command and the device is mandatory. See paragraph "Pairing between control and device" *p. 34*.

4.5 Connection diagram for S version



Connections to be made by the customer		
L - N - PE	Power supply 230 / 1 / 50	Check power
10v	Voltage reference signal	Voltage supplied by the motor (I max = 20 mA)
Y	0-10V DC signal to the motor	
Gnd	Reference signal	


⚠ Valve and external air kit damper must be controlled by the customer's adjustment.

4.6 Connections

Preliminary Warnings


- ⚠ The terminals for connecting the control panel and the CP presence contact are inserted in a plastic bag and placed on the inside of the electrical box cover.

1. Terminals



The terminals accept:

- rigid or flexible cables with a cross-section from 0.2 to 1 mm²
- rigid or flexible cables with a cross-section of 0.5 mm² if connecting two conductors in the same terminal
- rigid or flexible cables with a maximum cross-section of 0.75 mm² if equipped with a plastic collar ferrule




To connect the cables:

- ▶ strip 8 mm
- ▶ in the case of a rigid cable, insert it easily
- ▶ in the case of a flexible cable, use needle-nose pliers to assist
- ▶ push the cables in completely
- ▶ verify correct attachment by pulling them slightly


Remote control

- ⚠ The wall control panel must be ordered separately.
Position of the terminal blocks:

1. Terminal block (Panel rear view)



1. Terminals



To make connections between the wall control panel and the board:

- ▶ connect the power cables to the + - terminals
- ▶ connect the ModBus serial connection cables to terminals A and B

CP presence contact

Through this contact it is possible to connect an external device which inhibits the operation of the appliance, such as:


- window open contact
- remote on/off
- Presence infrared sensor
- Enabling badge
- remote season change

Operation

The contact is normally open.

- ▶ when the CP contact, connected to a clean, non-live contact, is closed, the device goes into stand-by

The symbol  is displayed on the screen

- ▶ when a button is pressed on the display, the symbol  appears

⊖ It is forbidden to connect the CP input in parallel with other electronic boards. Use separate contacts. The CP presence contact can be configured for heating and cooling operation via the (digital input) setting menu.

RS485 serial connection

The wall remote control can be connected via an RS485 line to one or more devices, up to a maximum of 16. The devices must be equipped with an electronic board suitable for remote control.

For the connection

- ▶ follow the connection diagram
- ▶ connect following the A and B indications






For pairing

- ▶ refer to chapter "Pairing between control and device" p. 34
- ⚠ Use a suitable shielded bipolar cable for RS485 serial connection with a minimum cross-section of 0.35 mm².
- ⚠ Keep the two-core cable separate from the power supply cables.
- ⚠ Route in such a way as to minimise the length of deviations.
- ⚠ Terminate the line with a 120 Ω resistor.
- ⊖ Star connections are prohibited.



4.7 Functions

Basic menu


To access the basic menu

- ▶ From display off, hold the button  for 10 seconds
The device turns on and  appears
- ▶ Hold until the indication  appears
- ▶ Release the button 
The symbol  appears


To navigate within the menu

- ▶ Use the icons  

To select menu items and confirm changes

- ▶ Press the icon 
Confirming the change moves to the next item.

To exit the menu

- ▶ press the icon  for 10 seconds
 - ▶ or wait 30 seconds for automatic shutdown
- ⚠ After a period of 30 seconds from the last action, the display turns off and the changes made are automatically saved.

Menu items

ot: AIR sensor offset (air sensor adjustment)

ur: Value read by the U.R. sensor

ut: RH sensor offset

uS: Humidity setpoint

uI: Humidity hysteresis

CF: Scale






ub: Buzzer volume

uu: Not used

uP: Not used

Set AIR sensor offset






To set the air sensor adjustment

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
*By default, it is set to 0.
The setting range is from a minimum of -12.0 °C to a maximum of 12.0 °C.*

Set RH sensor offset






- ⚠ Only change after finding actual deviations compared to a real measurement made with professional equipment.

To set the RH sensor adjustment

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm






Set humidity setpoint

To set the humidity setpoint

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
The setting range varies from 20.0% to 90.0%.




Set humidity hysteresis

To set the humidity hysteresis

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
The setting range is from a minimum of 1 to a maximum of 30.

Scale

To change the temperature unit






- ▶ select 
- ▶ Press  to change settings
- ▶ Select °C or °F
- ▶ Press  to confirm
By default, the temperature unit is °C.

Advanced menu



⚠ **To access the advanced menu, you must first access the basic menu. See paragraph "Basic menu" p. 32.**

Through the control panel you can access the advanced menu.


To access the advanced menu

- ▶ from the basic menu press 
-  appears
- ▶ press the  button once
-  appears
- ▶ press  to confirm and access
The advanced menu is accessed.




To navigate within the menu

- ▶ Use the icons  

To select menu items and confirm changes

- ▶ press  for 2 seconds
Confirming the change moves to the next item.

To exit the menu

- ▶ press  for about 10 seconds
 appears
- ▶ press  for about 10 seconds
The display turns off.
- ▶ or wait 30 seconds from the last action
The display turns off automatically.

⚠ After a period of 30 seconds from the last action, the display turns off.

Menu items

Ad: Not used

Pr: Not used

di: Options for the digital input






rH: Radiant heating options with R20

rC: Radiant cooling options with R20

UC: Not used

Adjust volume

To change the control volume

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
By default, the volume is set to 5.

⚠ The volume changes after confirming the modification.




Ac: Not used

Ah: Not used


Fr: Not used

Select the digital input

To change the digital input

- ▶ select 
- ▶ Press  to change settings
- ▶ select CP for presence contact (default)
- ▶ select CO for cooling open
- ▶ select CC for cooling close
- ▶ Press  to confirm
By default, the digital input is set to CP.

⚠ To return to the default settings, set the digital input to "CP".

⚠ By selecting one of the other inputs (CO, CC), the seasonality is locked and can no longer be changed using the  button on the control.

Set the radiant options in heating with R20

⚠ To modify the rH function, you need to have the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.

⚠ To modify the settings, refer to the instruction sheet of the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.

Set the radiant options in cooling with R20



⚠ To modify the rC function, you need to have the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.

⚠ To modify the settings, refer to the instruction sheet of the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.


Pairing between control and device

⚠ The matching procedure between control and luminaire is mandatory in case of a connection between several luminaires.

To pair the controller with the device

- ▶ from the powered-on controller, simultaneously press  and  for about 10 seconds
In the display area, where the setpoint is indicated, the number of connected devices appears.
The indicated value is flashing.

1. Red LED
2. Green LED
3. Black button
4. Electrical box




On the electrical box onboard the machine

- ▶ press the black button for 3 seconds
The green LED is flashing.
The red LED is on.
- ▶ wait for the procedure to finish
The green LED stops flashing.

On the wall control panel





The number assigned to the fancoil appears.
Then the number of connected devices appears.

- ▶ press  to exit the menu







Reset of the pairing


⚠ To reset the pairing settings, you first need to access the "Basic menu" p. 32.

To reset the pairing settings



- ▶ access the basic menu
- ▶ press 
- ▶ press 
Until you reach the  menu.
- ▶ press 

To reset a single fancoil









-  appears
- ▶ press 
 appears
- ▶ press  to access the menu
- ▶ use the icons   to navigate within the menu
The assigned numbers for the fancoils appear.

- ▶ select the fancoil you want to reset
- ▶ Press  to confirm
-- appears accompanied by an acoustic signal.
The device has been removed.

To exit the setting

- ▶ press  for 5 seconds
You exit the  setting
Return to menu 02.

To reset all the fancoils

-  appears
- ▶ press  until  appears
 appears
- ▶ press  to access the menu
- ▶ use the icons   to navigate within the menu
- ▶ select No to keep all the fancoils
- ▶ select Yes to reset the fancoils
- ▶ Press  to confirm

Operation of the LED interface present on the electrical box

If the device is in pairing mode

The green LED is flashing.

If the device is paired and operational

The green LED is on.

If the device has not been paired and is not operational

The green LED is off.
The red LED is on.

If the device is in an alarm state

The red LED is flashing.


⚠ The red LED will flash according to the type of alarm.
To check the type of alarm, refer to the next paragraph "Error indication" p. 34.

If there is a communication failure with the controller

The green LED and the red LED will flash once per second.

Error indication

The onboard card is equipped with LEDs which allow you to understand the operating status.

1. LED

⚠ The LED on the cover of the electrical box performs the same functions as the LED on the onboard machine card.

⚠ With the flashing LED, errors are indicated.

⚠ With the LED on, it indicates that there are no errors.

LED indications

- ▶ Flashing LED
Errors reported for display.
- ▶ LED off
Wall controller off
- ▶ Continuous flashing LED with a pause between each flash
Water temperature alarm not suitable.
- ▶ LED on
Wall controller on and no alarms present.
- ▶ LED 2 flashes / pause
Alarm: Internal fan motor failure or disconnected.
- ▶ LED 3 flashes / pause
Alarm: H2/T2 water temperature probe disconnected or faulty.
- ▶ LED 6 flashes / pause
Alarm: Communication error with wall control panel.




Display alarms on the wall control panel

⚠ In case of an alarm, the appliance still maintains some active functions.

⚠ To indicate alarms on the control panel for wall control, the fixed symbol  is displayed.

⚠ **To access the settings menu, you first need to access the basic menu. See paragraph "Basic menu" p. 32.**

To view errors on the wall control panel

- ▶ access the basic menu
- ▶ press 
↓ appears
- ▶ press 
↑ appears
- ▶ press  to access the menu
Subsequently, the number assigned to the fan coil appears and then the error is displayed.


Displayed alarms

- ▶ E2 Internal fan motor fault or disconnected
No device operation can be activated.
- ▶ E3 H2/T2 water temperature sensor disconnected or faulty
No device operation can be activated.
- ▶ E6 Unsuitable water temperature with automatic season function setting
The fan coil performs heating and cooling functions incorrectly. No operation of the device is possible.
- ▶ E8 Communication error
Communication error between the wall control panel and the fan coil.
- ▶ h2o Unsuitable water temperature
*In heating mode, the water temperature is below 30 °C.
In cooling mode, the water temperature is above 20 °C.*

⚠ The E8 error is displayed without performing the error viewing procedure on the wall control panel.

5. WALL MOUNTED CONTROL PCZ-EFB749

5.1 Interface



5.2 Installation


Description

The wall remote control is an electronic LED thermostat with a touch interface, capable of controlling multiple devices equipped with the same electronic board. It is equipped with a temperature and humidity sensor.

- ⚠ The command can control up to 16 devices.
- ⚠ This control panel can be managed remotely through the Aquarea Home App.

Mounting

- ⚠ The control panel for wall control must be installed inside a 503 electrical box.
- ⚠ Before proceeding with the installation of the wall control panel, it is necessary to prepare the wall for housing the 503 electrical box.




The wall control must be installed:

- on the outside walls
- at a height of approx. 1.5 m above the floor
- away from doors and windows
- away from heat sources such as radiators, fan coils, cookers, direct sunlight

⚠ The wall control is supplied already assembled in the package.


1. Control base
2. Wall control command



Before mounting on the wall:

- Separate the control base from the control panel


1. Fixing screws
2. Control base
3. Holes for fixing to the electrical box
4. 503 electrical box



For wall mounting of the control panel:

- Fix the control base to the 503 electrical box with screws
- Make the connections
- ⚠ Before making the connections, check that the terminal block of the command is on the right side.

1. 503 electrical box
2. Control base
3. Wall control command



- close the control panel


⚠ Be careful not to crush the wires when closing the control.

5.3 Single connection diagram

M1	M1: DC Inverter fan motor
PE	Ground connection
L-N	Electrical power connection 230 V / 50 Hz / 1 A
Y1	Water solenoid valve (output voltage 230V / 50 Hz / 1 A)
CH/C1	Generator cooling request contact (e.g., chiller or reversible heat pump). It activates in parallel with the solenoid valve output (Y1) with a 1-minute delay when the fan coil is in cooling mode and is on call (clean contact max 1 A)
BO/C2	Generator heating request contact (e.g., boiler or heat pump). It activates in parallel with the solenoid valve output (Y1) with a

1-minute delay when the fan coil is in heating mode and is on call (clean contact max 1 A)

CP	Presence contact (Normally open)
-BA+	Serial connection for remote wall control (respect polarization AB)
IN1	Input for clean contact 1 (not active)
LU	Board for pairing command and device
PU	On-board machine board
RC	Command for wall mounted control




⚠ This control panel can be managed remotely through the Aquarea Home App.

5.4 Multiple connection diagram


1. Command for wall mounted control
2. Device connection terminal block

3. Electronic board
4. Board for pairing command and device



⚠ With multiple command connections, pairing between the command and the device is mandatory. See paragraph "Pairing between control and device" *p. 44*.

5.5 Connection diagram for S version



Connections to be made by the customer		
L - N - PE	Power supply 230 / 1 / 50	Check power
10v	Voltage reference signal	Voltage supplied by the motor (I max = 20 mA)
Y	0-10V DC signal to the motor	
Gnd	Reference signal	


⚠ Valve and external air kit damper must be controlled by the customer's adjustment.

5.6 Connections

Preliminary Warnings


- ⚠ The terminals for connecting the control panel and the CP presence contact are inserted in a plastic bag and placed on the inside of the electrical box cover.

1. Terminals



The terminals accept:

- rigid or flexible cables with a cross-section from 0.2 to 1 mm²
- rigid or flexible cables with a cross-section of 0.5 mm² if connecting two conductors in the same terminal
- rigid or flexible cables with a maximum cross-section of 0.75 mm² if equipped with a plastic collar ferrule




To connect the cables:

- ▶ strip 8 mm
- ▶ in the case of a rigid cable, insert it easily
- ▶ in the case of a flexible cable, use needle-nose pliers to assist
- ▶ push the cables in completely
- ▶ verify correct attachment by pulling them slightly


Remote control

- ⚠ The wall control panel must be ordered separately.
Position of the terminal blocks:

1. Terminal block (Panel rear view)



1. Terminals



To make connections between the wall control panel and the board:

- ▶ connect the power cables to the + - terminals
- ▶ connect the ModBus serial connection cables to terminals A and B

CP presence contact

Through this contact it is possible to connect an external device which inhibits the operation of the appliance, such as:


- window open contact
- remote on/off
- Presence infrared sensor
- Enabling badge
- remote season change

Operation

The contact is normally open.

- ▶ when the CP contact, connected to a clean, non-live contact, is closed, the device goes into stand-by

The symbol  is displayed on the screen

- ▶ when a button is pressed on the display, the symbol  appears

⊖ It is forbidden to connect the CP input in parallel with other electronic boards. Use separate contacts. The CP presence contact can be configured for heating and cooling operation via the (digital input) setting menu.

RS485 serial connection

The wall remote control can be connected via an RS485 line to one or more devices, up to a maximum of 16. The devices must be equipped with an electronic board suitable for remote control.

For the connection

- ▶ follow the connection diagram
- ▶ connect following the A and B indications






For pairing

- ▶ refer to chapter "Pairing between control and device" *p. 44*
- ⚠ Use a suitable shielded bipolar cable for RS485 serial connection with a minimum cross-section of 0.35 mm².
- ⚠ Keep the two-core cable separate from the power supply cables.
- ⚠ Route in such a way as to minimise the length of deviations.
- ⚠ Terminate the line with a 120 Ω resistor.
- ⊖ Star connections are prohibited.



5.7 Functions

Basic menu


To access the basic menu

- ▶ From display off, hold the button  for 10 seconds
The device turns on and  appears
- ▶ Hold until the indication  appears
- ▶ Release the button 
The symbol  appears


To navigate within the menu

- ▶ Use the icons  

To select menu items and confirm changes

- ▶ Press the icon 
Confirming the change moves to the next item.

To exit the menu

- ▶ press the icon  for 10 seconds
- ▶ or wait 30 seconds for automatic shutdown

⚠ After a period of 30 seconds from the last action, the display turns off and the changes made are automatically saved.

Menu items

ot: AIR sensor offset (air sensor adjustment)

ur: Value read by the U.R. sensor

ut: RH sensor offset

uS: Humidity setpoint

uI: Humidity hysteresis

CF: Scale






ub: Buzzer volume

uu: Reset Wi-Fi

up: Wi-Fi activation

Set AIR sensor offset






To set the air sensor adjustment

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
*By default, it is set to 0.
The setting range is from a minimum of -12.0 °C to a maximum of 12.0 °C.*

Set RH sensor offset






⚠ Only change after finding actual deviations compared to a real measurement made with professional equipment.

To set the RH sensor adjustment

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm






Set humidity setpoint

To set the humidity setpoint

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
The setting range varies from 20.0% to 90.0%.




Set humidity hysteresis

To set the humidity hysteresis

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
The setting range is from a minimum of 1 to a maximum of 30.

Scale

To change the temperature unit






- ▶ select 
- ▶ Press  to change settings
- ▶ Select °C or °F
- ▶ Press  to confirm
By default, the temperature unit is °C.

Advanced menu



⚠ To access the advanced menu, you must first access the basic menu. See paragraph "Basic menu" p. 42.

Through the control panel you can access the advanced menu.

To access the advanced menu

- ▶ from the basic menu press 
- ▶  appears
- ▶ press the  button once
- ▶  appears
- ▶ press  to confirm and access
The advanced menu is accessed.

To navigate within the menu






- ▶ Use the icons  

To select menu items and confirm changes

- ▶ press  for 2 seconds
Confirming the change moves to the next item.

Adjust volume









To change the control volume

- ▶ select 
- ▶ Press  to change settings
- ▶ Increase or decrease the value with the icons  
- ▶ Press  to confirm
By default, the volume is set to 5.

⚠ The volume changes after confirming the modification.









Reset Wi-Fi

To reset Wi-Fi credentials and restore the device to its original configuration

- ▶ select 
- ▶ Press  to change settings
- ▶ use the icons  and  sequentially
Appears .
- ▶ press 
- ▶  appears to reset Wi-Fi credentials.
- ▶ Press  to confirm
The credentials have been reset.




Activate Wi-Fi

To activate Wi-Fi

- ▶ select 
- ▶ Press  to change settings
- ▶ use the icons  and  sequentially
Appears .
- ▶ press 
- ▶  appears to enable Wi-Fi pairing.
- ▶ Press  to confirm

⚠ The device remains visible on the App for the first 15 minutes after turning on the appliance.

To exit the menu

- ▶ press  for about 10 seconds
 appears
- ▶ press  for about 10 seconds
The display turns off.
- ▶ or wait 30 seconds from the last action
The display turns off automatically.

⚠ After a period of 30 seconds from the last action, the display turns off.

Menu items

Ad: Not used

Pr: Not used

di: Options for the digital input

rH: Radiant heating options with R20

rC: Radiant cooling options with R20

UC: Not used

Ac: Not used




Ah: Not used

Ed: Not used

Fr: Not used

Select the digital input

To change the digital input



- ▶ select 
 - ▶ Press  to change settings
 - ▶ select CP for presence contact (default)
 - ▶ select CO for cooling open
 - ▶ select CC for cooling close
 - ▶ Press  to confirm
- By default, the digital input is set to CP.*

- ⚠ To return to the default settings, set the digital input to "CP".


Pairing between control and device

- ⚠ The matching procedure between control and luminaire is mandatory in case of a connection between several luminaires.

To pair the controller with the device

- ▶ from the powered-on controller, simultaneously press  and  for about 10 seconds
- In the display area, where the setpoint is indicated, the number of connected devices appears. The indicated value is flashing.*

1. Red LED
2. Green LED
3. Black button
4. Electrical box




On the electrical box onboard the machine

- ▶ press the black button for 3 seconds
- The green LED is flashing.*
- The red LED is on.*
- ▶ wait for the procedure to finish
- The green LED stops flashing.*

On the wall control panel

The number assigned to the fancoil appears.

- ⚠ By selecting one of the other inputs (CO, CC), the seasonality is locked and can no longer be changed using the  button on the control.


Set the radiant options in heating with R20

- ⚠ To modify the rH function, you need to have the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.
- ⚠ To modify the settings, refer to the instruction sheet of the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.

Set the radiant options in cooling with R20

- ⚠ To modify the rC function, you need to have the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.
- ⚠ To modify the settings, refer to the instruction sheet of the MZS accessory - Single Zone Module for radiant system, code PCZ-EG1028.





Then the number of connected devices appears.

- ▶ press  to exit the menu








Reset of the pairing

- ⚠ To reset the pairing settings, you first need to access the "Basic menu" p. 42.



To reset the pairing settings

- ▶ access the basic menu
- ▶ press 
- ▶ press 
- Until you reach the  menu.*
- ▶ press 





To reset a single fancoil





-  appears
- ▶ press 
-  appears
- ▶ press  to access the menu
- ▶ use the icons   to navigate within the menu
- The assigned numbers for the fancoils appear.*
- ▶ select the fancoil you want to reset
- ▶ Press  to confirm
- appears accompanied by an acoustic signal.*
- The device has been removed.*

To exit the setting

- ▶ press  for 5 seconds
- You exit the  setting*
- Return to menu 02.*

To reset all the fancoils

-  appears
- ▶ press  until  appears
-  appears

- ▶ press  to access the menu
- ▶ use the icons   to navigate within the menu
- ▶ select No to keep all the fancoils
- ▶ select Yes to reset the fancoils
- ▶ Press  to confirm

Operation of the LED interface present on the electrical box

If the device is in pairing mode

The green LED is flashing.

If the device is paired and operational

The green LED is on.

If the device has not been paired and is not operational

The green LED is off.

The red LED is on.

If the device is in an alarm state

The red LED is flashing.

- ⚠ The red LED will flash according to the type of alarm. To check the type of alarm, refer to the next paragraph "Error indication" p. 45.


If there is a communication failure with the controller

The green LED and the red LED will flash once per second.

Error indication

The onboard card is equipped with LEDs which allow you to understand the operating status.

1. LED




- ⚠ The LED on the cover of the electrical box performs the same functions as the LED on the onboard machine card.
- ⚠ With the flashing LED, errors are indicated.
- ⚠ With the LED on, it indicates that there are no errors.






LED indications

- ▶ Flashing LED
Errors reported for display.
- ▶ LED off
Wall controller off
- ▶ Continuous flashing LED with a pause between each flash
Water temperature alarm not suitable.
- ▶ LED on
Wall controller on and no alarms present.
- ▶ LED 2 flashes / pause
Alarm: Internal fan motor failure or disconnected.
- ▶ LED 3 flashes / pause
Alarm: H2/T2 water temperature probe disconnected or faulty.
- ▶ LED 6 flashes / pause
Alarm: Communication error with wall control panel.

Display alarms on the wall control panel

- ⚠ In case of an alarm, the appliance still maintains some active functions.
- ⚠ To indicate alarms on the control panel for wall control, the fixed symbol  is displayed.
- ⚠ **To access the settings menu, you first need to access the basic menu. See paragraph "Basic menu" p. 42.**

To view errors on the wall control panel

- ▶ access the basic menu
- ▶ press 
 appears
- ▶ press 
 appears
- ▶ press  to access the menu
Subsequently, the number assigned to the fan coil appears and then the error is displayed.

Displayed alarms

- ▶ E2 Internal fan motor fault or disconnected
No device operation can be activated.
 - ▶ E3 H2/T2 water temperature sensor disconnected or faulty
No device operation can be activated.
 - ▶ E6 Unsuitable water temperature with automatic season function setting
The fan coil performs heating and cooling functions incorrectly. No operation of the device is possible.
 - ▶ E8 Communication error
Communication error between the wall control panel and the fan coil.
 - ▶ h2o Unsuitable water temperature
In heating mode, the water temperature is below 30 °C.
In cooling mode, the water temperature is above 20 °C.
- ⚠ The E8 error is displayed without performing the error viewing procedure on the wall control panel.

6. START-UP

6.1 Preliminary Warnings

- ⚠ **This section is dedicated to the Technical Service Centre. The specifications of the Technical Service Centre are described in chapter "Recipients" p. 4.**
- ⚠ **Initial commissioning must be carried out by the Technical Service Centre.**
- ⚠ **For detailed information on accessories, refer to the relevant instruction sheets.**

See chapter "Compatible accessories" p. 10

- ⚠ The customer must be present when the appliance is tested and informed of the contents of the manual and procedures. After commissioning, the manual and the warranty certificate must be handed over to the customer.
- ⚠ Before start-up, all works (electrical, hydraulic and air-flow connections) must have been completed.

6.2 First start-up

Preliminary Checks

Before commissioning, check that:

Operational checks

- all safety conditions have been met
- the unit has been properly secured to the supporting surface or wall
- the minimum technical spaces have been observed

Airflows

- the airflow connections have been made according to the instructions in the manual
- all airflow connections are correctly secured
- the ducting is correctly supported
- the ducting does not have any bottlenecks
- the ducting is thermally insulated

Electrical checks

- the cross-section of the power supply cables is adequate for the absorption of the appliance and the length of the connection made
- grounding is correctly performed
- the electrical connections have been established correctly
- all control wires are connected and that all electrical connections are secure

Settings

Auxiliary functions dip-switch setting


- ⚠ On the control circuit board, there are six dip switches; only the setting of dip switch A can be modified, the others must remain unchanged.
- ⚠ The dip-switch A is set to ON by default.

Dip-switch A

- modify the unit's performance

- in the ON position, the unit operates at nominal flow rates
- in the OFF position, the unit's performance is reduced, lowering air flow and noise

1. Dip-switch A



Start-up

After all checks have been carried out, the unit can be put into operation.

To activate the appliance:

- ▶ refer to the user manual
- ⚠ Should the startup be impeded by the water temperature, to temporarily force it, remove the water probe from the board. This will deactivate the control, allowing immediate startup. Reconnect the probe as soon as possible to ensure proper unit functionality.

Checks with the machine switched on

After starting up, check that

Operational checks:

- verify the different modes of operation
- verify that the appliance stops and then restarts
- switch the appliance off and on again and check that it restarts correctly
- the appliance operates within the recommended operating conditions (see technical specifications table)

- check that the air flow rates are correct

Hydraulic Checks

- check for proper condensate drainage

Electrical Checks

- the current absorbed is less than the maximum indicated in the technical data table
- the supply voltage value is within the set limits and does not fall below the nominal value -10 % during operation

6.3 Plant delivery

Once all the checks and controls on the correct operation of the plant have been completed, the installer must explain the following to the user:

- the basic functional characteristics of the appliance
- the instructions for use
- the routine maintenance

6.4 Switching off for extended periods

If the appliance is not used for a long period of time, the following steps must be taken:

► deactivating the device

► disconnect the power supply

⚠ To restart the appliance after it has been out of use for a long period, call in the Technical Service Centre.

7. MAINTENANCE

7.1 Routine maintenance

Annual operations

The once-a-year maintenance plan includes the following operations and checks and must be carried out by the Technical Service Centre or by qualified personnel.

Electrical circuit

Check:

- electrical supply voltage
- the electrical absorption
- connections tightening
- that there is no damage or excessive wear to electrical cables
- that the gaskets and sealing materials have not deteriorated to such an extent that they are no longer suitable for the purpose of preventing the development of flammable atmospheres inside
- the correct fixing of cable glands
- safety devices

Mechanical checks

Check:

- tightening of the screws, fans and electrical box, of the unit's external panelling
 - the state of the structure
- ⚠ Bad fixings result in abnormal noise and vibration.
- ⚠ If oxidised parts are present, treat them with suitable paints to eliminate or reduce oxidation.

Hydraulic controls

Check:

- the regular drainage of condensate
- cleaning the condensate collection trays
- cleaning the exhaust ducts





Airflow controls

Check:

- the regular flow of air
- cleaning of any intake grids
- cleaning the ducting

Cleaning

- cleaning or filter replacement
- cleaning the heat exchanger

Cleaning or filter replacement**1.** Lower filter guide**2.** Filter**1.** Side filter guide**2.** Filter


To remove:

- ▶ disconnect the power supply to the unit
- ▶ remove the screws from the lower filter guide
- ▶ remove the lower filter guide
- ▶ take out the filter
- ⚠ Pay attention to sharp surfaces

- ① If the condition of the filters is acceptable, they can be cleaned using a vacuum cleaner or a low-pressure compressor.
- ② If it is impossible to clean them, the filters must be replaced.

To reposition:

- ▶ proceed in reverse order



To remove:

- ▶ disconnect the power supply to the unit
- ▶ remove the screws from the filter port
- ▶ remove the filter port
- ▶ take out the filter
- ⚠ Pay attention to sharp surfaces
- ① If the condition of the filters is acceptable, they can be cleaned using a vacuum cleaner or a low-pressure compressor.
- ② If it is impossible to clean them, the filters must be replaced.


To reposition:

- ▶ proceed in reverse order

Cleaning the heat exchanger


Cleaning the heat exchanger

1. Lower panel



1. Heat exchanger

2. Condensate collection tray



- ▶ disconnect the power supply to the unit
- ▶ disconnect the condensate drain pipe
- ▶ access the heat exchanger
- ▶ gently proceed with the cleaning of the heat exchanger using a vacuum cleaner or a low-pressure compressor

To reposition:

- ▶ proceed in reverse order
- ⚠ Never touch the fins of the heat exchanger.

8. FAULTS AND REMEDIES

8.1 Preliminary Warnings

If one of the following faults is found:

- the ventilation does not activate even if hot or cold water is present in the hydraulic circuit
- the appliance is leaking water during heating operation
- the appliance is leaking water only in cooling mode
- the appliance makes excessive noise
- there is dew formation on the front panel

Follow the instructions below:

- ▶ immediately disconnect the power supply
 - ▶ close the water valves
 - ▶ contact an authorized service center or professionally qualified personnel
- ⚠ Work must be carried out by a qualified installer or a specialised service centre.
- ⊘ Personal intervention is prohibited.

8.2 Troubleshooting Table

DESCRIPTION OF FAULT	CAUSE	REMEDY
The fans are not active	The power supply is not switched on	Check the power supply on the fan
	The fan speed regulation device does not work	Check fan speed regulation device
	Incorrect electrical connections	Check electrical connections.
Insufficient air flow or pressure	Clogged filters	Clean filters
	Insufficient rotation speed	Increase rotation speed
	Piping or exchanger clogged	Clean piping or heat exchanger
Insufficient heat exchanger efficiency	Exchanger fins clogged	Clean exchanger surfaces
Excessive vibration and noise	Incorrect installation of the unit	Check unit brackets and fastenings
	Incorrect piping installation	Check brackets and pipe fixings
	Fan impeller imbalance	Check fan impeller condition
Water leaks from unit	Clogged condensate drain	Clean condensate drain
	Siphon not installed correctly	Check the correct installation of the siphon
Difficult start-up	Supply voltage too low	Check that the supply voltage is not below 10% of the rated voltage

8.3 Alarm table and card flashes

DESCRIPTION OF ALARM	CAUSE	REMEDY	CARD FLASHES
Water temperature alarm	Water request detected by the H2 probe not met (above 20 °C in cooling, below 30 °C in heating). It involves stopping the fan until the temperature reaches a suitable value to fulfill the request.	Check the water temperature or the positioning of the H2 probe	1 flash - off 3 seconds
Fan alarm	Fan connector faulty or feedback signal absent	Check the connection of the fan connector to the board	2 flashes - off 3 seconds
		Replace fan control cable	
Water probe alarm	Sensor breakage or failure to read	Check probe connection or replace sensor	3 flashes - off 3 seconds
Remote display connection alarm	Remote display connection error	Check electrical connections.	LED off
		Check that A and B are not reversed	
		Check the correct insertion of the display connection board on the main board	
Remote display communication alarm	No communication between display and board for at least 300 seconds	Check that A and B are not reversed	6 flashes - off 3 seconds
		Check the correct insertion of the display connection board on the main board	
Open GRID contact	Open GRID contact on the board	Check the presence of the closed bridge or connected contact	Continuous high-frequency flashing

9. TECHNICAL INFORMATION

9.1 Technical data


Models	u.m.	30	45	60	75
Fancoil airflow performance					
Maximum flow rate	m ³ /h	600	900	1200	1500
Available pressure	Pa	100	100	100	100
Single zone fancoil airflow performance					
Maximum flow rate	m ³ /h	300	300	300	300
Medium air flow	m ³ /h	205	205	205	205
Minimum air flow	m ³ /h	60	60	60	60
Heating performance (W 45; A 20) (1)					
Total power output	kW	3,90	5,70	7,40	9,00
Water flow rate	L/h	610	980	1300	1570
Pressure drop	kPa	29,00	22,00	21,00	12,00
Performance in single-zone heating (W 45; A 20) (1)					
Total power output	kW	2,20	2,20	2,20	2,20
Cooling performance (W 7; A 27) (2)					
Total power output	kW	3,80	5,50	7,20	8,10
Sensible heat capacity	kW	2,70	3,90	5,10	6,10
Water flow rate	L/h	600	950	1200	1400
Pressure drop	kPa	29,00	21,00	19,00	11,00
Performance in single-zone cooling (W 7; A 27) (2)					
Total power output	kW	2,10	2,10	2,10	2,10
Sensible heat capacity	kW	1,50	1,50	1,50	1,50
Room side fan					
Type		Forward-curved EC Brushless centrifugal fan			
Number	No.	2	3	4	5
Maximum absorbed current	A	0,61	0,91	1,22	1,52
Maximum absorbed power	W	140	210	280	350
Room side sound levels (UNI EN 3741; 3744) (3)					
Sound power transmitted to the Lw structure	dB (A)	60,0	61,0	62,0	64,0
Sound power radiated in the Lw channel	dB (A)	65,0	69,0	69,0	71,0
Average sound pressure at 1 m Lp	dB(A)	46,0	48,0	49,0	51,0
Average sound pressure at 3 m Lp	dB(A)	38,0	40,0	41,0	43,0
Heat exchanger (W 7; W 12) (4)					
1. Coil water temperature 45/40 °C; Room temperature 20 °C (EU Regulation 2016/2281) 2. Coil water temperature 7/12 °C; Room temperature 27 °C b.s. and 19° C b.u. (EU Regulation 2016/2281) 3. Data refers to the UNI EN 3741 and UNI EN 3744 standards 4. Supply water temperature 7 °C; Return water temperature 12 °C					

Models	u.m.	30	45	60	75
Type		Hydronic coil			
Number	No.	1	1	1	1
Coil water content	L	1,13	1,46	1,80	2,14
Maximum operating pressure	bar	10	10	10	10
Electrical characteristics					
Power supply	V / ph / Hz	230 / 1 / 50			
Maximum total absorbed power	kW	140,00	210,00	280,00	350,00
Protection rating	IP	X0			
Product dimensions					
Width	mm	790	990	1190	1440
Length	mm	695	695	695	695
Height	mm	240	240	240	240
Weight	kg	28,0	38,0	47,0	56,0
Connections					
Condensate drain connection	mm	20	20	20	20
Hydraulic connections	“EK	3/4”	3/4”	3/4”	3/4”
Supply air connection	mm	160	160	160	160
Extracted air connection (base x height)	mm	630 × 150	830 × 150	1030 × 150	1320 × 150
1. Coil water temperature 45/40 °C; Room temperature 20 °C (EU Regulation 2016/2281) 2. Coil water temperature 7/12 °C; Room temperature 27 °C b.s. and 19° C b.u. (EU Regulation 2016/2281) 3. Data refers to the UNI EN 3741 and UNI EN 3744 standards 4. Supply water temperature 7 °C; Return water temperature 12 °C					

9.2 Dimensions

Size 60


A	Electrical panel	C	Water inlet
B	Condensate drain	D	Water outlet




Size 80

A Electrical panel
B Condensate drain

C Water inlet
D Water outlet




Size 100



Size 120

A Electrical panel
B Condensate drain

C Water inlet
D Water outlet



Panasonic®

Panasonic Corporation
1006 Kadoma, Kadoma City, Osaka, Japan